



DEGREASER BBQ, GRILL & OVEN

BISON DEGREASER BBQ, GRILL & OVEN IS AN EXTREMELY POWERFUL, CONCENTRATED FOAM SPRAY



APPLICATION

Directions for use:

1. Wear protective gloves and observe all the other safety measures.
2. Release the childproof cap on the spray head by pressing it down while rotating a quarter turn to ON.
3. Spray undiluted onto the surface to be cleaned and allow it to work in for a few minutes.
4. Using an abrasive sponge, steel wool or brush, remove the encrusted remains and burnt fat.
5. Rinse with hot water.
6. Remove using a damp (dish)cloth or sponge.
7. Repeat this process if necessary.
8. Rotate the spray head to OFF after use.

N.B.: when cleaning separate components, place them on top of a protective material to prevent the powerful formula affecting the (porous) ground.

Points of attention: Before starting it is recommended to test the product on a small, unseen area.

STORAGE CONDITIONS

Keep in a dark, cool place, in an upright position, during storage or transportation

PRODUCT DESCRIPTION

Bison Degreaser BBQ, Grill & Oven is an extremely powerful, concentrated foam spray, specially developed for cleaning (gas) barbecues, ovens and grills.

FIELD OF APPLICATION

Suitable for cleaning (gas) barbecues, ovens and grills.

PROPERTIES

- Extremely powerful and easily removes burnt-on fat

PREPARATION

Personal safety: Wear protective gloves, protective clothing, eye protection, face protection.

Surface requirements: Do not use on surfaces that are hotter than $\pm 30^{\circ}\text{C}$. Do not use on worktops or untreated aluminium, plastic or wooden surfaces. If these items are affected, rinse immediately with copious amounts of water.