



RINNOVA PIASTRELLE

WHITE AND SHINY LIQUID FOR RECOVERING DISCOLORED TILE GROUT.

PRODUCT DESCRIPTION

White and shiny liquid for recovering discolored tile grout.

FIELD OF APPLICATION

Suitable for restoring the original white colour of grout between tiles. A single treatment is sufficient to restore the original luster in joints.

PROPERTIES

- Ready to use
- Easy to apply
- Liquid
- Powerful

PREPARATION

Working conditions: Do not use in temperatures $\leq +5^{\circ}\text{C}$.

Preliminary surface treatment: The joints to be treated should be dry and dust-free. If necessary, first degrease with a diluent or with an ordinary detergent and let dry.

Tools: In the cap mounted sponge.

APPLICATION

Directions for use:

Pull the cap straight from the tube (do not turn!). Shake tube well before use. Transfer the liquid to the joints of the tiles by pressing in the bottle lightly. Wipe the sponge from the bottom up over the joint. Let dry for about 60 minutes, then wipe the joints with a damp cloth. Then keep the joints dry for at least 4 hours.

Stains/residue: Clean the sponge after use with soap and water.

Points of attention: After applying Bostik Rinnova Piastrelle, keep the joints dry for at least 4 hours.

It is recommended not to apply Bostik Rinnova Piastrelle in areas with mould.

Do not swallow and keep out of the reach of children.

CURE TIMES*

Drying/Curing time: approx. 24 hours

* Curing time may vary depending on a.o. surface, product quantity used, humidity level and ambient temperature.

TECHNICAL PROPERTIES

Moisture resistance: Good

Temperature resistance: -20°C to $+80^{\circ}\text{C}$

TECHNICAL SPECIFICATIONS

Colour: White

Viscosity: approx. 0 mPa.s., Liquid

STORAGE CONDITIONS

At least 24 months after date of manufacturing. Limited shelf life after opening.

Store in properly sealed packaging in a dry place at between $+5^{\circ}\text{C}$ and $+25^{\circ}\text{C}$.